

CN-235


INDICATOR, FUEL TEMPERATURE

PART NO. 124.1207

COMPONENT MAINTENANCE MANUAL
WITH ILLUSTRATED PARTS LIST

77-10-08

Part Number 124.1201



IPL FIGURE 1

FIG & ITEM NO.	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE 1 2 3 4 5 6 7	EFF. CODE	UNITS PER ASSY
-1 1	124.1207		INDICATOR, INTER TURBINE (ITT)		RF
5	0305-0769		. CASE ASSEMBLY		
10	0349-0009		ATTACHING PARTS		
15	2118-0038		. SCREW, FLAT HEAD, 100°SST 2/56X0.12 IN.		4
20	2118-0039		. SOCKET (J2)		2
			. CONNECTOR P2, 2 PIN HOUSING		1
			* * * * *		
25	0317-0094		. INSULATION		1
30	0349-2034		. COVER LAMP		2
35	0338-0093		ATTACHING PARTS		
40	0349-0096		. GASKET LAMP COVER		2
			. SCREW, FLAT HEAD NO. 0-80 X 1/8 IN.		4
			* * * * *		
45	0318-0076		. LAMP		4
50	0356-0776		. METER ASSEMBLY		1
			ATTACHING PARTS		
60	2846-6108		. SCREW, HEXAGONAL SST 2-56 X 1/2 IN.		4
65	2833-0503		. WASHER, SPLIT LOCK SST NO. 2		4
70	2833-0503		. WASHER, FLAT SST NO. 2		4
			* * * * *		
75	2551-3802		. O-RING		2
80	0357-0425-05		. PLATE EMI FILTER		1
85	2705-0002		. FILTER, ELECTRO- MAGNETIC INTERFERENCE (EMI)		5

- ITEM NOT ILLUSTRATED